



# SUPERIOR

WASHER & GASKET CORP.

Part Number	Material	OD	ID	Free HT	Size	Thickness	
SP1-49	=Stainless-Steel	.164+-.005	.078+.005-0			.002+-.0005	Inner Race Spacers
SP1-1	=Stainless-Steel	.164+-.005	.078+.005-0			.004+-.0005	Inner Race Spacers
SP1-2	=Stainless-Steel	.164+-.005	.078+.005-0			.006+-.0005	Inner Race Spacers
SP1-46	=Stainless-Steel	.164+-.005	.078+.005-0			.008+-.0005	Inner Race Spacers
SP1-3	=Stainless-Steel	.164+-.005	.078+.005-0			.010+-.001	Inner Race Spacers
SP1-47	=Stainless-Steel	.164+-.005	.078+.005-0			.012+-.001	Inner Race Spacers
SP1-48	=Stainless-Steel	.164+-.005	.078+.005-0			.014+_001	Inner Race Spacers
SP1-4	=Stainless-Steel	.164+-.005	.078+.005-0			.016+-.001	Inner Race Spacers
SP1-50	=Stainless-Steel	.203+-.005	.093+.005-0			.002+-.0005	Inner Race Spacers
SP1-5	=Stainless-Steel	.203+-.005	.093+.005-0			.004+-.0005	Inner Race Spacers
SP1-6	=Stainless-Steel	.203+-.005	.093+.005-0			.006+-.0005	Inner Race Spacers
SP1-43	=Stainless-Steel	.203+-.005	.093+.005-0			.008+-.0005	Inner Race Spacers
SP1-7	=Stainless-Steel	.203+-.005	.093+.005-0			.010+-.001	Inner Race Spacers
SP1-44	=Stainless-Steel	.203+-.005	.093+.005-0			.012+-.001	Inner Race Spacers
SP1-45	=Stainless-Steel	.203+-.005	.093+.005-0			.014+-.001	Inner Race Spacers
SP1-8	=Stainless-Steel	.203+-.005	.093+.005-0			.016+-.001	Inner Race Spacers
SP1-51	=Stainless-Steel	.187+-.005	.125+.005-0			.002+-.0005	Inner Race Spacers
SP1-9	=Stainless-Steel	.187+-.005	.125+.005-0			.004+-.0005	Inner Race Spacers
SP1-10	=Stainless-Steel	.187+-.005	.125+.005-0			.006+-.0005	Inner Race Spacers
SP1-27	=Stainless-Steel	.187+-.005	.125+.005-0			.008+-.0005	Inner Race Spacers
SP1-11	=Stainless-Steel	.187+-.005	.125+.005-0			.010+-.001	Inner Race Spacers
SP1-28	=Stainless-Steel	.187+-.005	.125+.005-0			.012+-.001	Inner Race Spacers
SP1-29	=Stainless-Steel	.187+-.005	.125+.005-0			.014+-.001	Inner Race Spacers
SP1-12	=Stainless-Steel	.187+-.005	.125+.005-0			.016+-.001	Inner Race Spacers
SP1-13	=Stainless-Steel	.187+-.005	.125+.005-0			.031+-.002	Inner Race Spacers
SP1-14	=Stainless-Steel	.187+-.005	.125+.005-0			.063+-.002	Inner Race Spacers
SP1-30	=Stainless-Steel	.187+-.005	.125+.005-0			.094+-.002	Inner Race Spacers
SP1-15	=Stainless-Steel	.187+-.005	.125+.005-0			.125+-.002	Inner Race Spacers
SP1-31	=Stainless-Steel	.187+-.005	.125+.005-0			.188+-.002	Inner Race Spacers
SP1-16	=Stainless-Steel	.187+-.005	.125+.005-0			.250+-.002	Inner Race Spacers



# SUPERIOR

WASHER & GASKET CORP.

Part Number	Material	OD	ID	Free HT	Size	Thickness	
SP1-32	=Stainless-Steel	.187+-.005	.125+.005-0			.375+-.002	Inner Race Spacers
SP1-17	=Stainless-Steel	.187+-.005	.125+.005-0			.500+-.002	Inner Race Spacers
SP1-52	=Stainless-Steel	.250+-.005	.187+.005-0			.002+-.0005	Inner Race Spacers
SP1-18	=Stainless-Steel	.250+-.005	.187+.005-0			.004+-.0005	Inner Race Spacers
SP1-19	=Stainless-Steel	.250+-.005	.187+.005-0			.006+-.0005	Inner Race Spacers
SP1-36	=Stainless-Steel	.250+-.005	.187+.005-0			.008+-.0005	Inner Race Spacers
SP1-20	=Stainless-Steel	.250+-.005	.187+.005-0			.010+-.001	Inner Race Spacers
SP1-37	=Stainless-Steel	.250+-.005	.187+.005-0			.012+-.001	Inner Race Spacers
SP1-38	=Stainless-Steel	.250+-.005	.187+.005-0			.014+-.001	Inner Race Spacers
SP1-21	=Stainless-Steel	.250+-.005	.187+.005-0			.016+-.001	Inner Race Spacers
SP1-22	=Stainless-Steel	.250+-.005	.187+.005-0			.031+-.002	Inner Race Spacers
SP1-23	=Stainless-Steel	.250+-.005	.187+.005-0			.063+-.002	Inner Race Spacers
SP1-40	=Stainless-Steel	.250+-.005	.187+.005-0			.094+-.002	Inner Race Spacers
SP1-24	=Stainless-Steel	.250+-.005	.187+.005-0			.125+-.002	Inner Race Spacers
SP1-41	=Stainless-Steel	.250+-.005	.187+.005-0			.188+-.002	Inner Race Spacers
SP1-25	=Stainless-Steel	.250+-.005	.187+.005-0			.250+-.002	Inner Race Spacers
SP1-42	=Stainless-Steel	.250+-.005	.187+.005-0			.375+-.002	Inner Race Spacers
SP1-26	=Stainless-Steel	.250+-.005	.187+.005-0			.500+-.002	Inner Race Spacers
SP2-66	=Stainless-Steel	.375+-.005	.250+.005-0			.002+-.0005	Inner Race Spacers
SP2-27	=Stainless-Steel	.375+-.005	.250+.005-0			.004+-.0005	Inner Race Spacers
SP2-28	=Stainless-Steel	.375+-.005	.250+.005-0			.006+-.0005	Inner Race Spacers
SP2-60	=Stainless-Steel	.375+-.005	.250+.005-0			.008+-.0005	Inner Race Spacers
SP2-29	=Stainless-Steel	.375+-.005	.250+.005-0			.010+-.001	Inner Race Spacers
SP2-61	=Stainless-Steel	.375+-.005	.250+.005-0			.012+-.001	Inner Race Spacers
SP2-62	=Stainless-Steel	.375+-.005	.250+.005-0			.014+-.001	Inner Race Spacers
SP2-30	=Stainless-Steel	.375+-.005	.250+.005-0			.016+-.001	Inner Race Spacers
SP2-31	=Stainless-Steel	.375+-.005	.250+.005-0			.031+-.002	Inner Race Spacers
SP2-32	=Stainless-Steel	.375+-.005	.250+.005-0			.063+-.002	Inner Race Spacers
SP2-63	=Stainless-Steel	.375+-.005	.250+.005-0			.094+-.002	Inner Race Spacers
SP2-33	=Stainless-Steel	.375+-.005	.250+.005-0			.125+-.002	Inner Race Spacers



# SUPERIOR

WASHER & GASKET CORP.

Part Number	Material	OD	ID	Free HT	Size	Thickness	
SP2-64	=Stainless-Steel	.375+-.005	.250+.005-0			.188+-.002	Inner Race Spacers
SP2-34	=Stainless-Steel	.375+-.005	.250+.005-0			.250+-.002	Inner Race Spacers
SP2-65	=Stainless-Steel	.375+-.005	.250+.005-0			.375+-.002	Inner Race Spacers
SP2-35	=Stainless-Steel	.375+-.005	.250+.005-0			.500+-.002	Inner Race Spacers
SP2-80	=Stainless-Steel	.500+-.005	.313+.005-0			.002+-.0005	Inner Race Spacers
SP2-81	=Stainless-Steel	.500+-.005	.313+.005-0			.004+-.0005	Inner Race Spacers
SP2-82	=Stainless-Steel	.500+-.005	.313+.005-0			.006+-.0005	Inner Race Spacers
SP2-36	=Stainless-Steel	.500+-.005	.313+.005-0			.010+-.001	Inner Race Spacers
SP2-84	=Stainless-Steel	.500+-.005	.313+.005-0			.012+-.001	Inner Race Spacers
SP2-85	=Stainless-Steel	.500+-.005	.313+.005-0			.014+-.001	Inner Race Spacers
SP2-37	=Stainless-Steel	.500+-.005	.313+.005-0			.016+-.001	Inner Race Spacers
SP2-38	=Stainless-Steel	.500+-.005	.313+.005-0			.031+-.002	Inner Race Spacers
SP2-39	=Stainless-Steel	.500+-.005	.313+.005-0			.063+-.002	Inner Race Spacers
SP2-67	=Stainless-Steel	.562+-.005	.375+.005-0			.002+-.0005	Inner Race Spacers
SP2-68	=Stainless-Steel	.562+-.005	.375+.005-0			.004+-.0005	Inner Race Spacers
SP2-69	=Stainless-Steel	.562+-.005	.375+.005-0			.006+-.0005	Inner Race Spacers
SP2-70	=Stainless-Steel	.562+-.005	.375+.005-0			.008+-.0005	Inner Race Spacers
SP2-41	=Stainless-Steel	.562+-.005	.375+.005-0			.010+-.001	Inner Race Spacers
SP2-71	=Stainless-Steel	.562+-.005	.375+.005-0			.012+-.001	Inner Race Spacers
SP2-72	=Stainless-Steel	.562+-.005	.375+.005-0			.014+-.001	Inner Race Spacers
SP2-42	=Stainless-Steel	.562+-.005	.375+.005-0			.016+-.001	Inner Race Spacers
SP2-43	=Stainless-Steel	.562+-.005	.375+.005-0			.031+-.002	Inner Race Spacers
SP2-44	=Stainless-Steel	.562+-.005	.375+.005-0			.063+-.002	Inner Race Spacers
SP2-73	=Stainless-Steel	.562+-.005	.375+.005-0			.094+-.002	Inner Race Spacers
SP2-45	=Stainless-Steel	.562+-.005	.375+.005-0			.125+-.002	Inner Race Spacers
SP2-74	=Stainless-Steel	.562+-.005	.375+.005-0			.188+-.002	Inner Race Spacers
SP2-75	=Stainless-Steel	.562+-.005	.375+.005-0			.250+-.002	Inner Race Spacers
SP2-76	=Stainless-Steel	.562+-.005	.375+.005-0			.375+-.002	Inner Race Spacers
SP2-77	=Stainless-Steel	.562+-.005	.375+.005-0			.500+-.002	Inner Race Spacers
SP2-90	=Stainless-Steel	.750+-.005	.500+.005-0			.002+-.0005	Inner Race Spacers



# SUPERIOR

WASHER & GASKET CORP.

Part Number	Material	OD	ID	Free HT	Size	Thickness	
SP2-91	=Stainless-Steel	.750+-.005	.500+.005-0			.004+-.0005	Inner Race Spacers
SP2-92	=Stainless-Steel	.750+-.005	.500+.005-0			.006+-.0005	Inner Race Spacers
SP2-46	=Stainless-Steel	.750+-.005	.500+.005-0			.010+-.001	Inner Race Spacers
SP2-94	=Stainless-Steel	.750+-.005	.500+.005-0			.012+-.001	Inner Race Spacers
SP2-95	=Stainless-Steel	.750+-.005	.500+.005-0			.014+-.001	Inner Race Spacers
SP2-47	=Stainless-Steel	.750+-.005	.500+.005-0			.016+-.001	Inner Race Spacers
SP2-48	=Stainless-Steel	.750+-.005	.500+.005-0			.031+-.002	Inner Race Spacers
SP2-49	=Stainless-Steel	.750+-.005	.500+.005-0			.063+-.002	Inner Race Spacers